

MPX-65

QFX

WHERE THE PARTY BEGINS™



INSTRUCTION MANUAL



WARNING!

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER ON THIS SPEAKER. THERE ARE NO USER-SERVICEABLE PARTS INSIDE. REFER ALL SERVICING TO A QUALIFIED TECHNICIAN

To prevent fire or electric shock, do not expose this equipment to rain or moisture. Do not store or operate this product near any liquids, heat sources such as radiators, heat registers or under extreme weather conditions. Clean only with a dry cloth. Users should exhibit extra safety when the WARNING or CAUTION symbol appears in this instruction manual and follow all precautions as they are stated.



MPX-65 GUIDE

BATTERY

The MPX-65 is a speaker that operates on a rechargeable battery. Make sure you have fully charged the battery before the first use to maximize its lifespan. Once the power adapter is connected to a power source, it will begin to charge automatically (up to 8 hours to fully charge the battery). Even if the battery charge is low, it will power on when connected to a power source. When the battery is charging, the battery indicator light is red. When the battery is fully charged, the indicator light will turn off. After charging, disconnect the unit. When not in use, the speaker should always be TURNED OFF to prevent the unit from draining the battery. When the unit is not used for extended periods of time, the battery will gradually lose power. It is recommended to fully charge the battery at least every 60 days. When the battery is completely empty, the unit cannot operate at 100% volume when immediately connected to the power source. It is suggested to charge for a while before using it at 100% volume. The unit can operate and charge at a lower volume level. The volume level will increase as the unit is charging.

MPX-65 SYSTEM CONFIGURATIONS

1. Input mode: When a USB flash drive/TF card is inserted into the USB/TF input, The unit will automatically switch to USB/TF mode and start playing Mp3 audio files from USB flash drive/card TF.
2. FM mode: In FM mode, press Play/Pause to mute the audio.

MPX-65 BLUETOOTH

Bluetooth mode: Open the phone's Bluetooth. Find the Bluetooth name of the unit called "QFX MPX-65" to connect. After a successful connection, you can replay the music from the speaker. You will not need to reconnect Bluetooth when changing modes.

TWS CONNECTION MPX-65

1. True Wireless Stereo (TWS) works with two of the same QFX MPX-65 speakers. TWS can not support more than two speakers at the same time.
2. The first time, press the Play/Pause (TWS) button of one unit for 3 seconds. Then two speakers will be connected to each other.
3. Connect the phone: Open the phone's Bluetooth settings, search and connect the primary device Bluetooth name "QFX MPX-65"

NOTE: You will only see one "QFX MPX-65" on bluetooth device list once TWS pairing is successful.

4. Select music from phone and enjoy TWS playback in pairs with two speakers.
5. Exit TWS: Press and hold Play/Pause (TWS) button for 3 seconds to exit TWS function.



¡ADVERTENCIA!

PARA REDUCIR EL RIESGO DE DESCARGA ELÉCTRICA, NO quite la cubierta de este altavoz. No hay partes reparables por el usuario adentro. Remitir todo servicio a un técnico calificado

Para evitar incendios o descargas eléctricas, no exponga este equipo a la lluvia ni a la humedad. No almacene ni opere este producto cerca de líquidos, fuentes de calor como radiadores, registros de calor o bajo condiciones climáticas extremas. Limpiar solamente con un paño seco. Los usuarios deben mostrar una seguridad adicional cuando aparece el símbolo de ADVERTENCIA o PRECAUCIÓN en este manual de instrucciones y seguir todas las precauciones tal como se indican.



MPX-65 GUÍA

BATERÍA

El MPX-65 es un altavoz que funciona con una batería recargable. Asegúrese de haber cargado completamente la batería antes del primer uso para maximizar su vida útil. Una vez que el adaptador de corriente esté conectado a una fuente de alimentación, comenzará a cargarse automáticamente (hasta 8 horas para cargar completamente la batería). Incluso si la carga de la batería es baja, se encenderá cuando se conecte a una fuente de alimentación. Cuando la batería se está cargando, la luz indicadora de la batería está roja. Cuando la batería esté completamente cargada, la luz indicadora se apagará. Después de cargar, desconecte la unidad. Cuando no esté en uso, el altavoz siempre debe estar APAGADO para evitar que la unidad agote la batería. Cuando la unidad no se utiliza durante períodos prolongados de tiempo, la batería perderá energía gradualmente. Se recomienda cargar completamente la batería al menos cada 60 días. Cuando la batería está completamente vacía, la unidad no puede funcionar al 100% del volumen cuando se conecta inmediatamente a la fuente de alimentación. Se sugiere cargarlo por un tiempo antes de usarlo al 100% del volumen. La unidad puede funcionar y cargarse a un nivel de volumen más bajo. El nivel de volumen aumentará a medida que la unidad se esté cargando.

CONFIGURACIONES DEL SISTEMA MPX-65

1. Modo de entrada: Cuando se inserta una unidad flash USB/tarjeta TF en la entrada USB/TF, la unidad cambia automáticamente al modo USB/TF y comienza a reproducir archivos de audio Mp3 desde una memoria flash USB unidad/tarjeta TF.
2. Modo FM: En el modo FM, presione Reproducir/Pausa para silenciar el audio

MPX-65 BLUETOOTH


Modo Bluetooth: abra el Bluetooth del teléfono. Busque el nombre de Bluetooth de la unidad llamada "QFX MPX-65" para conectarse. Después de una partida exitosa, puedes reproducir la música desde el altavoz. No necesitarás volver a conectar el Bluetooth al cambiar de modo.

CONEXIÓN TWS MPX-65

1. True Wireless Stereo (TWS) funciona con dos de los mismos altavoces QFX MPX-65. TWS no puede admitir más de dos altavoces al mismo tiempo.
2. La primera vez, presione el botón Reproducir/Pausa (TWS) de una unidad durante 3 segundos. Luego dos oradores estarán conectados entre sí.
3. Conecte el teléfono: abra la configuración de Bluetooth del teléfono, busque y conecte el principal nombre del dispositivo Bluetooth "QFX MPX-65"

NOTA: Solo verá un "QFX MPX-65" en la lista de dispositivos Bluetooth una vez que el emparejamiento TWS se haya realizado correctamente.

4. Seleccione música del teléfono y disfrute de la reproducción TWS en pares con dos parlantes.
5. Salga de TWS: Mantenga presionado el botón Reproducir/Pausa (TWS) durante 3 segundos para salir de la función TWS.



1. TF card port: Inserting a TF card allows direct reading of data from the TF card and playback of content.
2. USB port: Insert the USB disk into the slot and automatically switch to card reading mode.
3. ON/OFF: Toggle the ON/OFF switch to turn the unit ON or OFF. To toggle the party lights ON or OFF, press and hold the MODE button.
4. DC5V Input: To charge speaker, insert the USB TYPE-C cable into the TYPE-C charging port.
5. LED light: When charging, the light is red, when fully charged, the light goes off, and the Bluetooth mode has a blue light flashing
6. MIC port: Insert the microphone into the microphone interface to use the microphone.
7. AUX BY: After connecting the auxiliary frequency cable to the audio output device, insert the two ends of the cable into the interfaces of the output device and speaker respectively, and then the audio can be played through the auxiliary input.
8. MODE: Short press to switch between Bluetooth, TF CARD, USB, LINE IN and FM modes.
9. **⏮/V-**
Short press for previous track press and hold for volume down
10. **⏭/SCAN**: In FM mode, press and hold to automatically scan FM stations. This process may take up to 2 minutes to complete.
11. **⏭/V+**
Short press to skip to the next track press and hold to increase the volume
1. Puerto para tarjeta tf: La inserción de una tarjeta tf permite la lectura directa de los datos de la tarjeta tf y la reproducción del contenido.
2. Puerto USB: Inserta el disco USB en la ranura y cambia automáticamente al modo de lectura de tarjetas.
3. Mueva el interruptor ON/OFF para encender o apagar la unidad. Para encender o apagar las luces de fiesta, mantenga presionado el botón MODE.
4. Interfaz de carga DC5V: Para cargar el altavoz, inserte el cable USB TYPE-C en el puerto de carga TYPE-C.
5. Luz LED: Cuando está cargando, la luz es roja, cuando está completamente cargado, la luz se apaga, y el modo Bluetooth tiene una luz azul intermitente
6. Puerto MIC: Inserta el micrófono en la interfaz de micrófono para utilizar el micrófono.
7. AUX por: Después de conectar el cable de frecuencia auxiliar al dispositivo de salida de audio, inserte los dos extremos del cable en las interfaces del dispositivo de salida y el altavoz respectivamente, y luego el audio se puede reproducir a través de la entrada auxiliar.
8. MODO: Pulse brevemente para cambiar entre los modos Bluetooth, TF CARD, USB, LINE IN y FM.
9. **⏮/V-**
Pulsación corta para pista anterior
Pulsación larga para bajar el volumen
10. **⏭/SCAN**: En modo FM, mantenga pulsado para buscar emisoras FM automáticamente. Este proceso puede tardar hasta 2 minutos.
11. **⏭/V+**
Pulsación corta para pasar a la pista siguiente
Pulsación larga para subir el volumen



LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at www.qfxusa.com for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the data stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, OR (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

QFX USA®, Inc.
RMA Processing
Customer Support Department
2957 E. 46th Street | Vernon, CA 90058

support@qfxusa.com
(800) 864-CLUB (2582) or (323) 457-9900
qfxusa.com
Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your product or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth Speakers	\$5.00	1 Year	1 Year
Personal Stereos	\$10.00	1 Year	1 Year
Portable Radio/Cassette	\$15.00	1 Year	1 Year
Large Portable Radio Cassette	\$20.00	1 Year	1 Year
Mobile Audio	\$10.00	1 Year	1 Year
Pro Audio SBX Systems	\$75.00	1 Year	1 Year
Pro Audio PBX Systems	\$75.00	1 Year	1 Year
Televisions	\$25.00	1 Year	1 Year
Telephones	\$10.00	1 Year	1 Year
Stand Fans	\$20.00	1 Year	1 Year
Portable Rechargeable Fans	\$15.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2025 ©


1-800-864-2582
Mon-Fri 9AM - 5PM (PST)


support@qfxusa.com
Mon-Fri 9AM - 5PM (PST)



www.qfxusa.com

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

THANK YOU.

QFX When the Party Begins!

We would love to hear about your MPX-65 Journey!
Tag us **@QFXUSA** to share your stories.

FOLLOW US @QFXUSA

