


R-82



WHERE THE PARTY BEGINS™



INSTRUCTION MANUAL



FUNCTIONS

1. LIGHT SWITCH
2. LED BULB SWITCH
3. TORCH
4. LED BULB
5. 5V OUT JACK
6. DC 4V JACK
7. FM BUTTON
8. AM BUTTON
9. SW BUTTON
10. DC 5V JACK
11. POWER SWITCH
12. TF CARD SLOT
13. USB SLOT
14. TUNING KNOB
15. PLAY/PAUSE BUTTON
16. NEXT "+" BUTTON
17. PREV "-" BUTTON
18. MODE BUTTON
19. LAMP
20. SPEAKER
21. TELESCOPIC ANTENNA
22. SOLAR PANEL

FUNCIONES

1. INTERRUPTOR DE LA LUZ
2. INTERRUPTOR BOMBILLA LED
3. ANTORCHA
4. BOMBILLA LED
5. CONECTOR DE SALIDA DE 5 V
6. DC 4V JACK
7. BOTÓN FM
8. BOTÓN AM
9. BOTÓN SW
10. TOMA CC 5V
11. INTERRUPTOR DE ENCENDIDO
12. RANURA PARA TARJETA TF
13. RANURA USB
14. BOTÓN DE SINTONIZACIÓN
15. BOTÓN PLAY/PAUSE
16. BOTÓN «+» SIGUIENTE
17. BOTÓN «-» ANTERIOR
18. BOTÓN MODO
19. LAMPARA
20. ALTA VOZ
21. ANTENA TELESCÓPICA
22. PANEL SOLAR

LES FONCTIONS

1. INTERRUPTEUR D'ÉCLAIRAGE
2. INTERRUPTEUR POUR AMPOULE LED
3. TORCHE
4. AMPOULE LED
5. PRISE DE SORTIE 5V
6. PRISE DC 4V
7. BOUTON FM
8. BOUTON AM
9. BOUTON SW
10. PRISE DC 5V
11. INTERRUPTEUR D'ALIMENTATION
12. EMPLACEMENT POUR CARTE TF
13. FENTE USB
14. BOUTON D'ACCORD
15. BOUTON LECTURE/PAUSE
16. BOUTON « + » SUIVANT
17. BOUTON « - » PRÉCÉDENT
18. BOUTON MODE
19. LAMPE
20. HAUT-PARLEUR
21. ANTENNE TÉLESCOPIQUE
22. PANNEAU SOLAIRE

RADIO FUNCTION

1. Turn on the power switch, is BT mode. Press the FM/SW/AM button, can choose AM, FM, SW.
2. Turn the "TUNING" button to choose the required station.
3. Adjust antenna position to get the best receiving effect.

FUNCIÓN RADIO

1. Pulse el botón FM/SW/AM para seleccionar AM, FM, SW.
2. Gire el botón «TUNING» para elegir la emisora deseada.
3. Ajuste la posición de la antena para obtener el mejor efecto de recepción.

FONCTION RADIO

1. Appuyez sur le bouton FM/SW/AM, vous pouvez choisir AM, FM, SW.
 2. Tournez le bouton « TUNING » pour choisir la station souhaitée.
 3. Réglez la position de l'antenne pour obtenir le meilleur effet de réception.
-

BLUETOOTH FUNCTION

Turn on the power switch, the unit will speak "BT MODE" then turn on the bt of cellphone or other mobile device with BT function, start to search a bt named "R-82" and pair with it, after successful pairing, it will beep. Now cellphone or other mobile device can play the music through bt on radio. You can select, play and pause the music by pressing NEXT "+" or PREV "-" buttons on radio or cellphone or other mobile devices. If you want to stop using bt function just need to turn off the bt in cellphone or other mobile devices.

FUNCIÓN BLUETOOTH

Conecte el interruptor de encendido y la unidad indicará «BT MODE». A continuación, conecte el bt del teléfono móvil u otro dispositivo móvil con función bt, comience a buscar un bt denominado «R-82» y emparejelo con él. Puede seleccionar, reproducir y pausar la música pulsando los botones NEXT «+» o PREV «-» en la radio o el teléfono móvil u otros dispositivos móviles. Si desea dejar de utilizar la función bt sólo tiene que apagar el bt in cellphone u otros dispositivos móviles.

FONCTION BLUETOOTH

Allumez l'interrupteur d'alimentation, l'appareil émettra le message « BT MODE », puis allumez le bt du téléphone portable ou d'un autre appareil mobile doté de la fonction bt, commencez à rechercher un bt nommé «R-82» et appairez-le, une fois l'appairage réussi, l'appareil émettra un signal sonore. Vous pouvez sélectionner, jouer et mettre en pause la musique en appuyant sur les boutons NEXT «+» ou PREV «-» de la radio ou du téléphone portable ou d'autres appareils mobiles. Si vous voulez arrêter d'utiliser la fonction bt, il suffit d'éteindre le bt dans le téléphone portable ou d'autres appareils mobiles.

USB 5V OUTPUT

The unit can charging the mobile phone and other mobile device.

SALIDA USB 5V

La unidad puede cargar el teléfono móvil y otros dispositivos móviles.

SORTIE USB 5V

L'unité peut charger le téléphone portable et d'autres appareils mobiles.

USB/TF CARD PLAYBACK FUNCTION

During radio program playing, insert USB/TF card, it will automatically switch to play from USB/TF card. You can press NEXT "+" or PREV "-" buttons on radio to select the music you need.

FUNCIÓN DE REPRODUCCIÓN DE TARJETAS USB/TF

Durante la reproducción de un programa de radio, inserte la tarjeta USB/TF y cambiará automáticamente a la reproducción desde la tarjeta USB/TF. Puedes pulsar los botones NEXT «+» o PREV «-» de la radio para seleccionar la música que necesites.

FONCTION DE LECTURE DES CARTES USB/TF

Pendant la lecture d'un programme radio, insérez une carte USB/TF et l'appareil passera automatiquement à la lecture à partir de la carte USB/TF. Vous pouvez appuyer sur les boutons NEXT «+» ou PREV «-» de la radio pour sélectionner la musique dont vous avez besoin.

TWS FUNCTION

After phone and host 1 connected successfully, open host 2 (same model) and enter bluetooth mode to play the music. Please press PLAY/PAUSE button both(host 1 and host 2) for 2 seconds at the same time. After successfully paired (prompt tone will rise on speaker), it will begin stereo broadcasting.

FUNCIÓN TWS

Después de que el teléfono y el host 1 se hayan conectado correctamente, abre el host 2 (mismo modelo) y entra en modo bluetooth para reproducir la música. Pulsa el botón PLAY/PAUSE durante 2 segundos al mismo tiempo (host 1 y host 2). Una vez emparejados con éxito (el altavoz emitirá un tono de aviso), comenzará la emisión estéreo.

FONCTION TWS

Une fois le téléphone et l'hôte 1 connectés avec succès, ouvrez l'hôte 2 (même modèle) et entrez en mode bluetooth pour écouter la musique. Appuyez simultanément sur les boutons PLAY/PAUSE (hôte 1 et hôte 2) pendant 2 secondes. Une fois l'appairage réussi (un signal sonore s'élève sur le haut-parleur), la diffusion stéréo commence.

BATTERY

1. The unit built in rechargeable battery, please note that first time need to charge 8 hours.
2. Normally, If use rechargeable battery, it can operate unit in following time.
3. If use for USB/TF, it can last over 270minutes.
4. If use for RADIO, it can last over 400 minutes
5. In order to prolong the battery life and product normal use, please keep the charging time with in 8 hours.

BATERÍA

1. La unidad incorporada en battery, please recargable en cuenta que la primera vez que la necesidad de cargar 8 horas.
2. Normalmente, si el uso de la batería recargable, puede operar la unidad en el tiempo siguiente.
3. Si el uso de USB / TF, puede durar más de 270minutos.
4. Si se usa para RADIO, puede durar más de 400 minutos.
5. Con el fin de prolongar la vida de la batería y el uso normal del producto, por favor, mantenga el tiempo de carga dentro de 8 horas.

BATTERIE

1. L'appareil est équipé d'une batterie rechargeable. Veuillez noter que la première fois, la batterie doit être chargée pendant 8 heures.
2. Normalement, l'utilisation d'une batterie rechargeable permet de faire fonctionner l'appareil dans les heures qui suivent.
3. En cas d'utilisation de l'USB/TF, l'appareil peut fonctionner pendant plus de 270 minutes.
4. Si l'appareil est utilisé pour la RADIO, il peut fonctionner pendant plus de 400 minutes.
5. Afin de prolonger la durée de vie de la batterie et de permettre une utilisation normale du produit, le temps de charge ne doit pas dépasser 8 heures.

NOTE

1. This product is not waterproof and should not be exposed to rain during outdoor use.
2. Do not install this equipment in a confined or building-in space such as a book case or similar unit, and remain a well ventilation conditions at open site. The ventilation should not be impeded by covering the ventilation openings with items such as newspaper, table-cloths, curtains etc.
3. **WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids, such as vases, shall not be placed on apparatus.
4. **WARNING:** The battery (battery or batteries or battery pack) shall not be exposed to excessive heat such as sunshine, fire or the like.
5. **WARNING:** The mains plug is used as disconnect device, the disconnect device shall remain readily operable.

NOTA

1. Este producto no es impermeable y no debe exponerse a la lluvia durante su uso en exteriores.
2. No instale este equipo en un espacio cerrado o edificado, como una librería o similar, y mantenga unas buenas condiciones de ventilación en un lugar abierto. No se debe impedir la ventilación cubriendo las aberturas de ventilación con elementos como periódicos, manteles, cortinas, etc.
3. **ADVERTENCIA:** Para reducir el riesgo de incendio o descarga eléctrica, no exponga este aparato a la lluvia ni a la humedad. No exponga el aparato a goteos ni salpicaduras y no coloque objetos que contengan líquidos, como jarrones, sobre el aparato.
4. **ADVERTENCIA:** La batería (batería o baterías o paquete de baterías) no debe exponerse a un calor excesivo como el del sol, el fuego o similares.
5. **ADVERTENCIA:** El enchufe de red se utiliza como dispositivo de desconexión, el dispositivo de desconexión debe permanecer fácilmente operable.

NOTE

1. Ce produit n'est pas étanche et ne doit pas être exposé à la pluie lors d'une utilisation en extérieur.
2. N'installez pas cet appareil dans un espace confiné ou encastré, tel qu'une bibliothèque ou un appareil similaire, et veillez à ce qu'il y ait une bonne ventilation à l'extérieur. La ventilation ne doit pas être entravée en couvrant les ouvertures de ventilation avec des articles tels que des journaux, des nappes, des rideaux, etc.
3. **AVERTISSEMENT :** Pour réduire les risques d'incendie ou d'électrocution, ne pas exposer cet appareil à la pluie ou à l'humidité. L'appareil ne doit pas être exposé à des gouttes ou à des éclaboussures et aucun objet rempli de liquide, tel qu'un vase, ne doit être placé sur l'appareil.
4. **AVERTISSEMENT :** La batterie (batterie ou piles ou bloc-piles) ne doit pas être exposée à une chaleur excessive telle que le soleil, le feu ou autre.
5. **AVERTISSEMENT :** Si la fiche secteur est utilisée comme dispositif de déconnexion, le dispositif de déconnexion doit rester facilement utilisable.



LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at www.qfxusa.com for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the date stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, OR (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

QFX USA®, Inc.
RMA Processing
Customer Support Department
2957 E. 46th Street | Vernon, CA 90058

 support@qfxusa.com
 (800) 864-CLUB (2582) or (323) 864-6900
 qfxusa.com
 Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your prouuct or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth vSpeakers	\$5.00	1 Year	1 Year
Personal Stereos	\$10.00	1 Year	1 Year
Portable Radio/Cassette	\$15.00	1 Year	1 Year
Large Portable Radio Cassette	\$20.00	1 Year	1 Year
Mobile Audio	\$10.00	1 Year	1 Year
Pro Audio SBX Systems	\$75.00	1 Year	1 Year
Pro Audio PBX Systems	\$75.00	1 Year	1 Year
Televisions	\$25.00	1 Year	1 Year
Telephones	\$10.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2025©



1-800-864-2582
Mon-Fri 9AM - 5PM (PST)



support@qfxusa.com
Mon-Fri 9AM - 5PM (PST)

www.qfxusa.com

THANK YOU.

QFX Where the Party Begins!

We would love to hear about your **R-82** journey!
Tag us **@QFXUSA** to share your stories.

FOLLOW US @QFXUSA

